

# Insertion and Extraction Tools

NEW

Series	Insertion Tool for GKS	Insertion and Extraction Tool for GKS Tip-Ø > Shaft-Ø	Insertion Tool for KS
GKS-001	SW-GKS		
GKS-002	SW-GKS	SW-ZW-GKS-100	SW-KS 100 / SW-KS-100 G <sup>(4)</sup>
GKS-003	SW-GKS		SW-KS-102
GKS-004	SW-GKS		
GKS-005	SW-GKS		
XXX-050	SW-GKS-081 <sup>(1)</sup>		SW-KS-050 G <sup>(4)</sup>
GKS-069	SW-GKS-187 B		SW-KS-080
XXX-075		SW-ZW-GKS-075	SW-KS-075 G <sup>(4)</sup>
GKS-080		SW-ZW-GKS-080	SW-KS-080
GKS-081	SW-GKS-081 <sup>(1)</sup>		SW-KS-080
GKS-098	SW-GKS		SW-KS-103
XXX-100	SW-GKS-100 B <sup>(1)</sup>	SW-ZW-GKS-100	SW-KS 100 / SW-KS-100 G <sup>(4)</sup>
GKS-101		SW-ZW-GKS-101	SW-KS-101
GKS-102		SW-ZW-GKS-112	SW-KS-102
GKS-103		SW-ZW-GKS-103	SW-KS-103
GKS-112		SW-ZW-GKS-112	SW-KS-112
GKS-113		SW-ZW-GKS-103	SW-KS-113
GKS-135	SW-GKS-100 B <sup>(1)</sup>	SW-ZW-GKS-100	SW-KS 100 / SW-KS-100 G <sup>(4)</sup>
GKS-181	SW-GKS-181 <sup>(1)</sup>	ZW-GKS-912	SW-KS-181
GKS-204	SW-GKS-912 A <sup>(2)</sup> / 912 B <sup>(3)</sup>	ZW-GKS-912	SW-KS-112
GKS-412		SW-ZW-GKS-112	SW-KS-112
XXX-422	SW-GKS-912 A <sup>(2)</sup> / 912 B <sup>(3)</sup>	ZW-GKS-912	SW-KS-112
GKS-502		SW-ZW-GKS-112	SW-KS-102
GKS-503		SW-ZW-GKS-103	SW-KS-103
GKS-550	SW-GKS-181 <sup>(1)</sup>		SW-KS-050 G <sup>(4)</sup>
GKS-710		ZW-GKS-912	SW-KS-112
GKS-713	SW-GKS		SW-KS-113
GKS-714	SW-GKS		SW-KS-113
GKS-725		SW-ZW-GKS-100	SW-KS-100
GKS-912	SW-GKS-912 A <sup>(2)</sup> / 912 B <sup>(3)</sup>	ZW-GKS-912	SW-KS-112
GKS-913		SW-ZW-GKS-103	SW-KS-113
GKS-967	SW-GKS		SW-KS-102
HSS-118		SW-ZW-GKS-112	SW-KS-112
HSS-120		SW-ZW-GKS-103	SW-KS-113
HSS-150	SW-GKS		
PKS-200/220	SW-GKS		SW-KS-102
PKS-300/299	SW-GKS		SW-KS-103
SKS-100		SW-ZW-GKS-100	SW-KS-100 G <sup>(4)</sup>
SKS-215		SW-ZW-GKS-112	SW-KS-112
SKS-415/425		SW-ZW-GKS-103	SW-KS-113
SKS 419/429	SW-SKS-419-429-300		
SKS 419/429	SW-SKS-419-429-500		

<sup>(1)</sup> Insertion Tool for Plunger with continuous Shaft  
<sup>(3)</sup> for Tip Style „09“

<sup>(2)</sup> universal usage  
<sup>(5)</sup> Extraction Tool

<sup>(4)</sup> free adjustable

**Note:**

Tools for Screw-in Test Probes page 170/171.  
Tools for RF-Probes can be found in our present RF Catalog .

## Ordering Example

Insertion and Extraction Tools for GKS 112:

SW - ZW - GKS - 112

Insertion Tools for GKS 912:

SW - GKS - 912 A or SW - GKS - 912 B


Bits for Insertion tools GKS 912:

E - SW - GKS - 912 A or E - SW - GKS - 912 B

Extraction Tool for Receptacles:

AW - KS - Set - ICT


**SW-GKS:** Universal Insertion Tool for GKS



**SW-KS-xxx G (4):** Variably adjustable Insertion Tool, for Receptacle with Press-ring (\* can be purchased individually)

**AW-KS-Set-ICT:** Extraction Tool for KS (ICT)

NEW



The Set for extraction of Receptacles contains the Bits E-AW-KS-xxx for Test Probe series GKS-040/050/075/100:

Extraction Tool for Set ICT	AW-KS-Set-ICT
Bit for KS-040 (Spare Part)	E-AW-KS-040
Bit for KS-050 (Spare Part)	E-AW-KS-050
Bit for KS-075 (Spare Part)	E-AW-KS-075
Bit for KS-100 (Spare Part)	E-AW-KS-100